



Download
Manual




Growatt New Energy

Shenzhen Growatt New Energy Co., Ltd
4-13/F, Building A, Sino-German(Europe) Industrial Park,
Hangcheng Ave, Bao'an District, Shenzhen, China

T +86 0755 2747 1942
E service@ginverter.com
W www.ginverter.com

GR-UM-142-A-03



Installation & Operation Manual

List

1 Overview

- 1.1 Product Overview
- 1.2 Applicable Personnel

2 Safety Precautions

- 2.1 Safety Overview
- 2.2 Symbol
- 2.3 Meaning of Symbol

3 Product Introduction

- 3.1 Appearance
- 3.2 Dimensions
- 3.3 Nameplate
- 3.4 Working Principle
- 3.5 Inverter Storage
- 3.6 Grid Types
- 3.7 AFCI Detection Function
- 3.8 Anti-PID Function

4 Unpacking

5 Installation

- 5.1 Basic Installation Requirements
- 5.2 Installation Environment Requirements
- 5.3 Moving Requirements
- 5.4 Wall Mounted Installation
- 5.5 Installing the Inverter

6 Connecting Cables

- 6.1 Connection on AC side
- 6.2 Connection on DC side
- 6.3 Connection of Communication Cables
- 6.4 Connecting the Ground Cables

7 System Commissioning

- 7.1 Inverter Commissioning
- 7.2 Modes
- 7.3 LED display

8 Monitoring

- 8.1 Remote Data Monitoring
- 8.2 Local Data Monitoring

9 Maintenance

- 9.1 Routine Maintenance
- 9.2 Trouble Shooting

10 Product Specification

11 Decommissioning

12 Quality Assurance

13 Contact Us

1 Overview

1.1 Product Overview

This manual is aimed at providing sufficient information and installing instruction for consumers buying Shenzhen Growatt New Energy Co.,Ltd (short as Growatt) MAX Series solar inverters. Please read this manual carefully before using the MAX series inverters and store the manual in a reachable place for an authorized technician. No further notice if there is any change in this manual.

1.2 Applicable Personnel

Only qualified electrical technicians are allowed to install MAX series inverter. With reading through this manual and following all the precautions, qualified electrical technician can properly install MAX serial inverter, finish trouble shooting and communication settings.

If there is any problem during the installation, the installer can either log on www.ginverter.com and leave a message or call consumer service hotline +86 755 27471942.

2 Safety Precautions

2.1 Safety Overview

1>Before installation please make sure reading through this manual, any damage caused by improper installation, Growatt reserve the right to disclaim any warranty.

2>All the operations and connections must be done by trained qualified electrical technician.

3>During installation except for terminals, do not touch any inside part of the inverter.

4>All the electrical connections must meet local country's safety regulations.

5>If you need maintenance for this inverter, please contact our local authorized installing and maintenance technician.

6>You must get the local power supplier's permit before connecting this inverter to the grid.

Handle Process:

| | |
|--|---|
|  WARNING | <ul style="list-style-type: none"> The inverter is heavy, please treat with care while handling, in case of crushing injury. |
|--|---|

Installation:

| | |
|---|---|
|  NOTICE | <ul style="list-style-type: none"> Before installation, please read through this manual, any damage caused by improper installation, Growatt reserve the right to disclaim any warranty. |
|  DANGER | <ul style="list-style-type: none"> Ensure that the MAX is not connected to a power supply and is not power on before installation. |

| | |
|--|---|
|  WARNING | <ul style="list-style-type: none"> Please follow this installation manual as installation condition environment, space and so on. Please install the inverter in a dry and ventilated environment, otherwise may affect the performance of the inverter. Please follow the installation procedures in this manual. |
|--|---|

Electrical Connections:

| | |
|--|---|
|  DANGER | <ul style="list-style-type: none"> Before electrical connection, please ensure the inverter DC switch is at "OFF" also disconnect AC switch, otherwise the high voltage from inverter may cause life risk. Only trained authorized electrical technician can do the electric connection also please follow the connection procedures in this manual along with local country's regulations. High voltage may cause electric shocks and serious injury please do not touch the inverter. Please do not store inverter in area with flammable and explosive material. |
|  WARNING | <ul style="list-style-type: none"> Each inverter must install one AC breaker; AC breaker is forbidden to share with other inverters. It is forbidden to add load between inverter and breaker. If the cable is thick, after tightening the cable do not shake it and ensure the cable is well-connected and then start the inverter. Loose connection may cause overheat. Before connecting between PV panels and inverter please ensure the positive and negative poles are correct connected. |

Maintenance and replacement:

| | |
|--|--|
|  DANGER | <ul style="list-style-type: none"> Must be installed by trained and authorized electrical technician and accurately follow this manual. Please disconnect the DC and AC switch for at least five minutes, all the operations should be carried after power disconnection. If there is PV isolation low alarm, the inverter case may be ungrounded, please do not touch the inverter case. High voltage of inverter may result in electric shock. |
|  WARNING | <ul style="list-style-type: none"> For better cooling purpose, please regularly clean the fans. Do not use air pump to clean the fans, cause it may damage the fans. |

Other:

| | |
|--|---|
|  | <ul style="list-style-type: none"> •After you receiving the inverter please check the packing materials for damage,if there is any damage please contact your supplier. |
|  WARNING | <ul style="list-style-type: none"> •The Max PV input voltage should not exceed 1100V. •For the disposed inverter,the consumer should dispose it according to local disposal rules for electrical equipment waste. |

2.2 Symbol Conventions

| Symbol | Description |
|--|---|
|  DANGER | Indicates an imminently hazardous situation which,if not avoided, will result in serious injury or death. |
|  WARNING | Indicates potentially hazardous situation which,if not avoided,will result in serious injury or death. |
|  CAUTION | Indicates potentially hazardous situation which,if not avoided,will result in minor or moderate injury. |
|  NOTICE | Indicates certain hazardous situation which,if not avoided,will result in property damage. |
|  | Reminds operator to read installation manual before operating or installing inverter. |

2.3 Lable Description

| Symbol | Name | Meaning |
|---|------------------------------|--|
|  | High Voltage Electric Shock | Inverter operating with high voltage,any operation regarding inverter need to be done by trained and authorized electrical technician. |
|  | Burn Warning | Do not touch a running inverter cause it generates high temperature on the case. |
|  | Protective Grounding | Connect inverter to grounding bar. |
|  | Delay discharge | Residual voltage exists after the inverter is powered off,it takes 5 minutes for the inverter to discharge to the safe voltage. |
|  | Read the installation manual | Reminds operator to read installation manual before operating or installing inverter. |
|  | DC | Means this terminal is for DC side. |
|  | AC | Means this terminal is for AC side. |
|  | CE Mark | The inverter complies with the requirements of the applicable CE guidelines. |

3 Product Introduction

3.1 Appearance

Front view:




Fig 3.1

Bottom view(Terminal):




Fig 3.2

Side view:




Fig 3.3

| Mark | Description | Mark | Description |
|------|-------------|------|------------------------------|
| A | Ring | H | USB_B port(optional) |
| B | LED | I | RS 485 cable waterprofe head |
| C | DC switch | J | Outside CT port(optional) |
| D | Vent valve | K | Antenna port(optional) |

| | | | |
|---|---------------------|---|--------------------------|
| E | PV terminal board | L | AC cable waterproof head |
| F | Safety ground screw | M | Fan |
| G | USB_A port | N | Heatsink |

Notice: For inverters with 90-100K capacity, need add another string of PV terminal.

3.2 Basic Data

| Model | Size (mm) | | | Weight (kg) |
|------------------------------|-----------|--------|-----------|-------------|
| | Width | Height | Thickness | |
| 50-80K Inverters | 860 | 600 | 300 | 82 |
| 50-80K Inverter with package | 1035 | 735 | 465 | 98 |

3.3 Nameplate

| PV Grid Inverter | |
|-------------------------------|--------------------------|
| Model name | MAX 80KTL3 LV |
| Max. PV voltage | 1100 d.c.V |
| PV voltage range | 200-1000 d.c.V |
| PV Isc | 32 d.c.A*7 |
| Max. input current | 26 d.c.A*7 |
| Max. output power | 80000 W |
| Max. apparent power | 88800 VA |
| Nominal output voltage | 3W/N/PE 230/400 a.c.V |
| Max. output current | 128.8 a.c.A |
| Nominal output frequency | 50/60 Hz |
| Power factor range | 0.8leading~0.8lagging |
| Safety level | Class I |
| Ingress protection | IP65 |
| Operation ambient temperature | -25°C - +60°C |
| VDE0126-1-1 | |
| | |
| Made in China | |

Note: Other models of MAX series share the same label design with MAX50KTL3 LV, only with different model name and parameters, detail parameter please refer to specification in Chapter 10.

3.4 Working Principle

The MAX series inverter works as follows:

- 1>The PV panels gather solar to generate DC power to inverter.
- 2>With input current detection circuit, it can monitor all the PV panels' working status and use MPPT to track the maximum power point.
- 3>With inverter circuit change DC power to AC power, and feed power back to grid per grid requirement.
- 4>With output isolation relay can isolate AC output and grid, if anything goes wrong on either inverter side or grid side, isolation relay can disconnect inverter immediately.

On-grid connection system diagram:




Fig 3.4

| symbol | Description | symbol | Description |
|--------|-------------|--------|----------------|
| A | PV string | C | Electric meter |
| B | Inverter | D | Grid |

3.5 Inverter Storage


- 1>Do not unpack the inverter and store it in a ventilation dry place .
- 2>Keep the storage temperature at -25°C - +60°C and humidity at 0-95%.
- 3>A maximum of four inverters with package can be stacked.
- 4>If the inverter has been long-term stored, inspections and tests should be conducted by qualified personnel before it is put into use.



After being stored for a month or longer, the inverter's time and date could be wrong, you need set the time and date before using, for more details please refer to Chapter 7.1 inverter commissioning.

3.6 Grid Types

The MAX series, 50-80KTL3 LV inverters connect to the grid like following drawing 3.5,60- 80KTL3 MV inverters connect to the grid like following drawing3.6.



3.7 AFCI Detection Function

AFCI (Arc Fault Circuit Interrupter) is a kind of circuit protection device, the main function is to prevent the fire caused by fault arc.The electrical insulation aging, breakage, loose connection, air breakdown caused by air humidity and so on, all of these may cause an electric spark,which is called arc.

The AFCI function of the MAX series inverter is optional, and the detection equipment is assembled inside the inverter. When an arc-drawing condition is detected on the PV input side, the arc current could be detected by the CT assembled on the PV input-side wire. Then the inverter will shut down. Meanwhile, the inverter will display the corresponding fault message and the buzzer will sound, which could help to avoid harm and economic loss to the user.

NOTE: AFCI function is optional.

3.8 Anti-PID Function

The full name of PID is Potential Induced Degradation. Since the PID effect, a large amount of charge could accumulate on the surface of the photovoltaic module, which makes the surface passivation of the module worse. Eventually, the fill factor, open-circuit voltage, and short-circuit current of the module are reduced, and the power of the photovoltaic module is attenuated.

The Anti-PID function uses the principle of reversible PID changes. MAX series inverters rectify AC voltage at night and boost it to generate a DC voltage. The DC voltage is connected to PV + and the ground respectively. When add a positive bias voltage to the module to make the PID effect reverse,the Anti-PID function could repair the photovoltaic modules at night and prolong the service life of photovoltaic modules.

NOTE: Anti-PID function is optional.

4 Unpacking

Checking before installation

- 1>Before unpacking the inverter, check the outer packing materials for damage.
- 2>After unpacking the inverter, check that the contents are intact and complete. If any damage is found or any component is missing, contact your supplier.

Package contents:




Fig 4.1

| Mark | Descriptions | Number |
|------|---|----------------------------------|
| A | Inverter | 1 |
| B | Wall mount | 1 |
| C | PV+ terminal, PV- terminal | 12/12 (6 MPPT) 14/14 (7 MPPT) |
| D | SC50-10 | 5 |
| E | Installation manual | 1 |
| F | Warranty card | 1 |
| G | Antenna(opt) | 1 |
| H | Removal tool of PV terminals | 1 |
| I | Removal handle(opt) | 2 |
| J | Wall mount screw | 5 |
| K | Rs485 terminal | 2 |
| * | AC waterproof joint fastening ring(opt) | 1/2 |

Installation 5



CAUTION

- To prevent device damage and personal injury, keep balance when moving the inverter because it is heavy.
- Do not place the inverter with its wiring and signal terminals at the bottom contacting with floor or any other object because the terminals are not designed to support the weight of inverter.
- When placing inverter on the floor, put foam or paper under the inverter to protect its cover.

5.1 Basic Installation Requirements

- A. Ensure that the installation wall is solid enough to bear the inverter(Inverter weight please refer to installation manual Chapter3, 3.2).
- B. There must be enough installation space to fit the size of inverter.
- C. Do not install inverter on flammable or heat-intolerant buildings.
- D. This inverter is IP 65 protection, you can install it indoor or outdoor.
- E. To avoid inverter performance de-rate due to the over heat, please do not expose the inverter under direct sunlight.
- F. The installation humidity should be from 0-95%.
- G. The surrounding temperature of inverter should be from -25°C - +60°C.
- H. Inverter should be installed in a vertically or rear tilted surface, please refer to following drawings.




Fig 5.1

- I. To ensure the inverter can work smoothly and easy for personnel to operate, please notice there is sufficient space for inverter, refer to following drawing.




Fig 5.2

- J. Do not install inverter close to strong electromagnetic signal.
- K. Install the inverter out of children's reach.

5.2 Installation Environment Requirements

A. Although the inverter's protection level is IP 65, to extent inverter lifespan you still need to avoid rain and snow, please refer to following drawings.




Fig 5.3

B. To reduce the de-rate performance of the inverter and extend inverter's life span, we strongly recommend you install an awning, for the distance between an awning and inverter, please refer to following drawing.




Fig 5.4

C. When you install multiple inverters on one surface, inverters should be installed as following drawing.




Fig 5.5

D. Do not install inverter into an enclosed space like following drawing.




Fig 5.6

5.3 Moving Requirements

| | |
|---|---|
|  WARNING | <ul style="list-style-type: none"> •The inverter is heavy, please move it with care and keep balance to avoid personnel injury. •Do not place the inverter with its wiring and signal terminals at the bottom contacting with floor or any other object because the terminals are not designed to support the weight of inverter. |
|---|---|

Plan 1:

1>As shown in Fig5.7, use a rope to tie at ring and handle, lift the inverter from package and move to installation position.

2>When you are moving the inverter, please keep the balance.

Notice: There is front and bottom mark on the package.

Plan 2(Optional):

1>As shown in Fig5.8, 4-6 persons lift the inverter out of package, swap the ring to moving handles.

2>When you are moving the inverter, please keep the balance.

Notice: There will be front and bottom mark on the package.




Fig 5.7




Fig 5.8

5.4 Wall Mount Bracket Installation

Before install the inverter you need install the wall mount bracket so that the inverter can be firmly installed on the wall.

Wall mount plan:




Fig 5.9

1>Use the wall mount plate as a template drill holes on the wall and put in expansion bolts.




Fig 5.10

Notice: Expansion bolt should be installed on solid walls with at least 100mm thickness.

2>Follow the following drawing put the bolt to install the wall mount plate on the wall.




Fig 5.11

Notice: Do not install inverter unless you have confirmed the wall mount plate has been firmly installed on the wall.

5.5 Installing The Inverter

After the wall mount bracket has been firmly installed on the wall , put the inverter on that plate.

1>Use the rope(must meet the weight requirement of the inverter) through two rings and lift the inverter up, just as following Figure.

2>Before hanging the inverter on the wall mount bracket use screws to fix the inverter and please keep the inverter balance.

3>Check the inverter if it is firm enough and lock all the screws.

Connecting Cable 6

Decisive Voltage Class (DVC) indicated for ports

| Port Name | Class |
|-----------|-------|
| AC | C |
| DC | C |
| DRMS | A |
| RS485&USB | A |




Fig 5.12




Fig 5.13




Fig 5.14

6.1 Connection on AC side



DANGER

- Before electrical connection, please ensure the inverter DC switch is at "OFF" also disconnect AC switch, otherwise the high voltage from inverter may cause life risk.
- Only trained authorized electrical technician can do the electric connection also please follow the connection procedures in this manual along with local country's regulations.
- High voltage may cause electric shocks and serious injury please do not touch the inverter.
- Please do not store inverter in area with flammable and explosive material.



WARNING

- Each inverter must install one AC breaker, AC breaker is forbidden to share with other inverters.
- It is forbidden to add load between inverter and breaker.

Preparation before connection:

- 1> Disconnect inverter DC switch and AC breaker or switch.
- 2> When you lock the AC cable's screw, the torque force should be 100kgf·cm. When you lock the cover screw, the torque force should be 35kgf·cm.
- 3> Measure the grid voltage and frequency, please refer to chapter 10.

AC breaker specification:

| Inverter model | Breaker model |
|-------------------|---------------|
| MAX 50KTL3 LV | 100A/400Vac |
| MAX 60KTL3 LV | 125A/400Vac |
| MAX 70KTL3 LV | 160A/400Vac |
| MAX 80KTL3 LV | 160A/400Vac |
| MAX 60KTL3 MV | 100A/500Vac |
| MAX 70KTL3 MV | 125A/500Vac |
| MAX 80-100KTL3 MV | 160A/500Vac |

| Inverter Model | Copper wire cross-sectional area(mm ²) | Copper wire recommendation(mm ²) | Aluminum wire recommendation(mm ²) |
|-------------------|--|--|--|
| MAX 50KTL3 LV | 25-35 | 35 | 50 |
| MAX 60KTL3 LV | 25-35 | 35 | 50 |
| MAX 70KTL3 LV | 35-50 | 50 | 70 |
| MAX 80KTL3 LV | 35-50 | 50 | 70 |
| MAX 60KTL3 MV | 25-35 | 35 | 50 |
| MAX 70KTL3 MV | 35-50 | 50 | 70 |
| MAX 80-100KTL3 MV | 35-50 | 50 | 70 |

Notice: The cable must be unbroken.
If you connect the aluminum wire, please consult our technology.

AC side connection steps:

| | |
|--|--|
|  WARNING | <ul style="list-style-type: none"> If the cable is thick, after tightening the cable do not shake it and ensure the cable is well-connected and then start the inverter. Loose connection may cause overheat. |
|--|--|

1>Following drawing shows inverter's AC terminal, L1, L2, L3 are three live lines, N is Neutral line.
Notice: The screw is M8 screw.




Fig 6.1

2>Firstly, unscrew the waterproof cover, then put the cable through the cover, pile the cable base on terminal size(17mm recommended), use a wire stripper to connect cable. and terminal, tighten all the terminal screws.




Fig 6.2

Diagram of how to install a terminal:



Fig 6.3

3>Put the water proof cover back to the inverter and fill the cover with fireproof mud, just as following drawing.

| | |
|--|---|
|  WARNING | <ul style="list-style-type: none"> Must tighten the waterproof cover, otherwise there will be a risk of water leakage. |
|--|---|




Fig 6.4

6.2 Connection On DC Side

| | |
|---|--|
|  DANGER | <ul style="list-style-type: none"> •Before electrical connection, please ensure the inverter DC switch is at "OFF" also disconnect AC switch, otherwise the high voltage from inverter may cause life risk. •Only trained authorized electrical technician can do the electric connection also please follow the connection procedures in this manual along with local country's regulations. •High voltage may cause electric shocks and serious injury please do not touch the inverter. •Do not place flammable or explosive materials around the inverter. |
|---|--|

Notice: The sunlight will generate voltage on the solar panels, after serial connection, the high voltage may injure personnel, so before connect DC input cable you need cover solar panels with light-tight materials and make sure the inverter DC switch is at "OFF" status, otherwise high voltage may injure personnel.

| | |
|--|--|
|  WARNING | <ul style="list-style-type: none"> •Each string's maximum open circuit voltage cannot exceed 1100Vdc, otherwise it could lead to fire or damage the inverter. If the inverter was damaged by higher maximum open circuit voltage (higher than 1100Vdc) product warranty will be forfeited and Growatt will not take any responsibility. •The inverter shall be used with IEC 61730 Class A rating PV module. •When the group is suspended, be sure to use dust plugs to block up to prevent entering the water into the dust. |
|--|--|

- 1>Each string solar panels should be same brand and same model.
 - 2>Under any circumstance, the maximum short circuit current should not exceed 32A.
 - 3>The total panels power should not exceed 1.25 times of inverter input power.
 - 4>To optimize system settings, recommend two strings with same amount solar panels.
- Notice: Connectors need to be fit with male and female terminals, before connecting panels with inverter please make sure the positive pole and negative pole, namely the solar panels' positive pole connect to "+" negative pole connect to "-".




Fig 6.5

- 5>Decide the length of peeling base on cable terminal, use the wire stripper to connect cable and terminal, and separately connect to specific connector.

6>Connect the positive and negative poles to inverter terminals, different inverter's maximum single string input current please refer to following table.

| Inverter model | Max. single string input current |
|---------------------|----------------------------------|
| MAX serial inverter | 13A*2 |

7>Cable specifications:

| Inverter model | Cross-sectional area(mm ²) | Recommendation (mm ²) | Cable outer diameter(mm) |
|---------------------|--|-----------------------------------|--------------------------|
| MAX serial inverter | 4-6 | 4 | 4.5-7.8 |

- Notice:
1. Under any circumstance, the total current of all strings cannot exceed the inverter's maximum current.
 2. Do not touch any working solar panels.
 3. Make sure the cable is unbroken.

6.3 Connection Of Communication Cables

6.3.1 RS485 port

RS485 can be used for single inverter communication also can be used for multiple inverters(Maximum 32 inverters), the longest distance is 500 meters, high speed (Baud rate 38400), the communication port as following.

485 can be used for single inverter communication also can be used for multiple inverters(Maximum 32 inverters), the longest distance is 500 meters, high speed (Baud rate 38400), the communication port as following.

It is recommended to use shielded twisted pair for RS485 cable. When a single inverter communicates, the shielding layer of the RS485 cable needs to be connected to the ground and can be connected to the PE of the inverter case; When multiple inverters are connected in parallel, both RS485 interfaces must be used. The shield of the RS485 cable should be connected to the GND of the RS485 terminal, and then the GND of all inverters should be shorted together by wire. Finally, Connect the communication ground GND of the inverter that is last connected to the monitoring device to the protective ground of the inverter housing.




Fig 6.6A

Fig 6.6B

Notice: When multiple inverters are connected in parallel or the transmission distance is long, it is recommended to change the jumper cap of CN5 pin header on the Connector Board of the last inverter from the default 2/3 pin to 3/4 pin (As shown in Fig6.6B). The reason for this is to increase the matching resistance.

For the MAX inverter, the standard model has RS485 port, please follow following instructions when you connect the inverter.

- 1) Use the screw to tighten communication cables for 485A port and 485 B port.
- 2) Unscrew the M25 waterproof cover, take out the waterproof plug.
- 3) Just follow the following drawing to put 485 communication cable through the water proof plug and connect it to RS485 port.
- 4) Inverter connected with 485 communication cable in daisy chain, the end of 485 cable will connect to shinemaster for remote control.

Notice: Please refer to shinemaster operation manual for details.
When you lock the 485 wire screw, is locked, the torque force should be 4kgf·cm.




Fig 6.7

6.3.2 USB port

MAX series inverter is configured with USB_A port (optional USB_B port) , USB_A port can be connected to USB to WIFI module, Shine GPRS-X, Shine Wifi-X, Shine 4G-X, Shine Link-X, etc. The monitoring module is selected to implement the monitoring function. In addition, you can quickly update the software via a USB flash drive.

Steps to install the monitoring module:

- 1> Loose waterproof cover, and remove waterproof plug.
- 2> As shown in Figure 6.8A, plug the USB to WIFI dongle to USB_A port, the indicating LED will lit up.
- 3> As shown in Figure 6.8B, make sure that ▲ is on the front side, plug the monitoring module to USB_A port, and tighten the screws.

Note: Mobile APP instruction please refer to 7.2.1.

The optional USB_B port can communicate with PC through the USB 2.0 printer cable.

Note: When the operator leaves , please take the monitoring module and data cable away, and tighten the waterproof cover to avoid water entering the interface.




Fig 6.8A




Fig 6.8B

6.3.3 GPRS /4G antenna

For the MAX inverter the standard model has Antenna port, when you are using GPRS monitoring please follow following instructions.

- 1) Connect the antenna to the antenna port.
- 2) Check the antenna is firmly fixed.

Notice: For GPRS operation please refer to 7.1.1.




Fig 6.9

6.4 Connecting The Ground Cables

In this solar system all the unloaded metal components and cases should be connected to the ground.

Single inverter need grounding over a PE point, multiple inverters need connect all the inverter PE cable and solar panels shelves to the same grounding point to achieve equipotential.

The grounding steps as following:

Take out the ground screw at the inverter bottom, connect the ground cables as following figure.

Notice: 1. The machine is safely separated from the lightning protection and the distance is as far as possible.

2. Do not expose Grounding terminal in the air and precaution for the rain.

3. When you lock the case ground screw, the torque force should be 60kgf·cm.




Fig 6.10

According to the relevant provisions of IEC 61643-32 "Connecting to photovoltaic devices surge protectors - selection and use of guidelines", whether for household or outdoor photovoltaic power plants, it is necessary to ensure the implementation of lightning protection measures for photovoltaic systems:

| | |
|---|---|
|  WARNING | <p>The lightning protection measures for photovoltaic systems shall be carried out in accordance with the corresponding national standards and IEC standards. Otherwise, photovoltaic devices such as components, inverters and power distribution facilities may be damaged by lightning.</p> <p>In this case, the company does not carry out warranty and assumes any responsibility.</p> |
|---|---|




Fig 6.11

1) It is generally recommended to install lightning protection devices (such as lightning rods / lightning protection belts and down conductors) to prevent lightning from hitting the PV array.

2) Lightning protection devices and down-conductors and related equipment in photovoltaic systems (including photovoltaic panels, cables, power distribution equipment) should maintain a safe separation distance S.

Suggested value of S: According to the general 5 storey height (about 15m) building roof, S takes 2.5m enough, this distance can be simplified according to the inverse relationship of the floor height.

A. When the safety distance S is satisfied:

The position ①③ of the figure should be equipped with a lightning protection module. In general, it is recommended to install Type II in position ① and Type I in position ③.

B. When the safety and safety distance S is not met:

In addition to position 3, Type I lightning protection module should be installed in Figure ①②④.

3) The lightning down conductor and the equipment ground wire eventually sink at a total ground point, but the two cannot share the wire. That is, the equipment grounding wire should be pulled separately, and the wire diameter requirement $>6\text{mm}^2$ when the safety interval distance S is satisfied.

4) About the above lightning protection lightning receptor system related design reference GB/T 21714.3-2015.

7 Commissioning

7.1 Commission The Inverter



• If the inverter is stored over one month, its default time and date may look wrong, the time and date should be reset before connection to the grid.

The inverter will be set to the appropriate model according to the standards of different countries or regions before leaving the factory. For example, the inverters shipped to Australia are configured as Australian model in the factory.

Note: The inverter is configured for Australia at the factory.

7.1.1 Set inverter address

After inverter is started normally, inverter address can be set via RS485/USB converting to WIFI. When multiple inverters are connected in parallel via RS485, the inverter must be set to a different communication address. When a single inverter communicates, the default communication address can be used.

Note: The default communication address of the inverter is 1, which can be set to 1-254.

7.1.1.1 Set RS485 address with Shinebus

The 485 address of the inverter can be modified by Shinebus, This operation is performed by a professional.

7.1.1.2 Set RS485 address on ShinePhone APP

Refer to 8.2 download mobile APP ShinePhone and connect to inverter WIFI to enter local monitoring page, this operation is performed by a professional.

1>Click "Parameters";

2>Enter passwor.(When you use it for the first time, you need to set the password first. Click "Reset password" to enter the OSS account number and password. The distributor and installer can apply for the OSS account from Growatt. Click "Sign in" to set the password. After the setting is successful, you can start using it.)

3>Click top item "COM Address";

4>Click the "Read" button in the upper right corner to read the current communication address of the inverter;

5> Set inverter com address;

6>Read inverter com address to ensure setting is successful;




Fig 7.1

7.1.2 Set inverter time and date

Method 1:

Please refer to section 8.2.1 and login ShinePhone APP. Click "system time(45-50)" to set inverter time and date on the parameter setting page.




Fig 7.2

Method 2:

Please connect GPRS antenna to the inverter as section 6.3.3, when the inverter is powered on, connect the inverter to the server as section 8.1.2, then the inverter time will be updated automatically.

7.2 Operation Mode

7.2.1 Waiting mode

When the DC voltage is more than 200Vdc, inverter will be powered on and enters the "waiting" state.

At this mode, inverter will check the system parameter. If the system is normal and PV voltage is more than 250Vdc, inverter will try to connect to the grid.

7.2.2 Working mode

At this mode, inverter work normally, and the Power or fault code indicator light shows the power delivered by the inverter to the grid.

When the DC voltage is more than 250Vdc, inverter converts the DC power generated by the PV modules into AC power and supplies them to the grid.

When the DC voltage is lower than 250Vdc, inverter will enter into "waiting" state and try to connect to the grid, at this status, inverter consume very small power to check the internal system status.

Note: only when the PV modules supply enough power (voltage \geq 200Vdc) then the inverter will start automatically.

7.2.3 Fault mode

Inverter intelligent control system will continuously monitor and adjust system status. When there is a fault detected, LED will show the fault message.

Note: Please refer to section 8.2 to check the fault message and take corrective measures.

7.2.4 Off mode

When the sunlight is weak or no light, inverter will stop working automatically. When it is off, inverter will not consume grid power or PV module. At the same time, the LED of inverter will be turned off.

Note: When PV string DC voltage is too low (\leq 150Vdc), inverter will be off.

7.3 LED Display

Inverter current operation status can be visually checked from LED display directly.




Fig 7.3

Fig 7.4

| Description of LED status | | | |
|---------------------------|----------------------------|--|--|
| Position of LED | Type of LED | Inverter status | LED status |
| A | PV voltage indicator light | PV voltage reaches grid voltage | Green light is on |
| | | PV voltage does not reach the grid voltage | Light is not on |
| B | AC voltage indicator light | Inverter is in the grid state | Green light is on |
| | | No AC voltage | Light is not on |
| | | With AC voltage, inverter is in the grid countdown state | The green light flashes slowly, and the alarm or fault indicator light is not on |

| Description of LED status | | | |
|---------------------------|-------------------------------------|--|--|
| Position of LED | Type of LED | Inverter status | LED status |
| B | AC voltage indicator light | With AC voltage, inverter is in a fault state | The green light flashes slowly, and the alarm or fault indicator light is steady red. |
| C | Alarm or fault indicator light | Inverter works normally | Light is not on |
| | | Inverter is in alarm state | Red light flashes slowly |
| | | Inverter is in fault state | Red light is on |
| D | Communication indicator light | Inverter has external communication, such as RS485, GPRS, etc. | Green light is on |
| | | Inverter has no external communication | Light is not on |
| | | Inverter upgrade or USB interface is reading and writing data | Green light flashes |
| E | Power or fault code indicator light | Inverter is in the grid state | The eight LEDs from left to right represent the power of the inverter: if 8 green lights are on, it represents 100% of the inverter power. As shown in Figure 7.3, it represents 37.5% of the inverter power, and so on. |
| | | Inverter is in fault state | The five LEDs from right to left represent 1, 2, 4, 8, 16 in turn, representing the fault code of the inverter. As shown in Figure 7.4, the LED status represents 2, and then 2 is added to the specific 99 to get 101, so it can be known that the inverter reported error 101. |

8.1 Remote Data Monitoring

MAX series inverter remote monitoring ways include APP(ShinePhone) and server Web page, RS485, GPRS, 4G, PLC(reserved) can satisfy both ways of monitoring.

8.1.1 Mobile phone APP(ShinePhone) remote monitoring

1>Scan the following QR code, or download from Android store or App store by searching "Shinephone", download and install software.



Fig 8.1

Note: 1. Make you it's the latest version.

2. Please find more details on <http://server.growatt.com>.

2>Users can register their mobile APP account by following the steps below:

Run ShinePhone, go to login page, click "register". Registration is required to fill in the information, with the * is required, the agreement is mandatory, you can log in to the main interface of ShinePhone after registration, the registration page and the main interface are as shown below.

Shinephone login and main page:




Fig 8.2




Fig 8.3

Device page:

- 1>Main page top middle is the name of current plant, user can click the "v" button to switch to other plants under this account.
- 2>User can add datalogger,check datalogger and add plant by click "+" button at the top right corner.
- 3>Top half shows current plant power, revenue today and total production.
- 4>My device list shows current plant device, user can see more details by click the device, left cross the device to stick the device and edit, edit operation includes change device alias, icon,and delete device.




Fig 8.4 add datalogger




Fig 8.5 datalogger list




Fig 8.6 add plant

Datalogger:

- 1>User can add more datalogger under the particular plant.
- Way: Click "+" in the upper right corner of the device page and select "Add Collector (WiFi/GPRS, etc.)", as shown in Figure 8.7.
- Note: You can choose to manually enter the collector serial number for addition, or you can add it by scanning the barcode on the nameplate.




Fig 8.7

- 2>User can add datalogger at the datalogger list page to add a datalogger, edit, delete, configure etc.
- 3>User can add more plants with the add Plant function.

Device page and function:

- 1>Device page: User can click the device to see more details, the device page show current power and Energy today and daily power chart, user can find more with control,parameter, data and Events page.
- 2>Control: user set inverter on/off, set active power, set reactive power, set PF, set inverter time, set grid voltage high, set grid voltage low. The operation password is : inverter+date, for example inverter20170722.
- 3>Parameter: user can see device SN, rated power, firmware version, PV1 voltage, current, and power etc.



Fig 8.8



Fig 8.9



Fig 8.10

- 4>Data page: user can see the PV power, voltage, current, R phase power, S phase power, S phase power, T phase power, output power by day, month, year, by finger up cross the screen.

- 5>Events: User can see the fault message if there it is.




Fig 8.11



Fig 8.12

Fig 8.14

8.1.2 GPRS /4G

8.1.2.1 Register account

1>Register account

Open browser, input "server.growatt.com", click "New User" at login page, input the necessary information then go back to login page, input the registered username and password, click "Sign In".

2>Add datalogger

At Plant page, click device manage, then click add datalogger, input the SN and valid code then save, after device is powered on, datalogger will show after 5mins, also the device will come online(our device is monitored by datalogger, so need to add the datalogger here first).



Fig 8.13

Welcome : MAXtest (Normal user) Exit

MAX Dashboard Plant User Cen Setting Download English

Plant data device list event list Plant Detail

datalog inverter storage hybrid inverter Pcs MAX Hps more

| No. | SN | alias | device type | user name | connect status | |
|-----|------------|------------|-------------|-----------|----------------|----------|
| 1 | 79Z0000024 | 79Z0000024 | ShineGPRS | MAXtest | connection | /192. |
| 2 | 79Z0000015 | 79Z0000015 | ShineGPRS | MAXtest | connection | /192. |
| 3 | WLC082102D | WLC082102D | ShineGPRS | MAXtest | connection | /192. |
| 4 | 79Z0000020 | 79Z0000020 | ShineGPRS | MAXtest | connection | /192.168 |
| 5 | 79Z0000008 | 79Z0000008 | ShineGPRS | MAXtest | connection | /192.168 |
| 6 | 79Z0000033 | 79Z0000033 | ShineGPRS | MAXtest | connection | /192 |
| 7 | 79Z0000023 | 79Z0000023 | ShineGPRS | MAXtest | connection | /192. |
| 8 | 79Z0000014 | 79Z0000014 | ShineGPRS | MAXtest | connection | /192. |
| 9 | WLC0821017 | WLC0821017 | ShineGPRS | MAXtest | lost | /192. |
| 10 | 79Z0000021 | 79Z0000021 | ShineGPRS | MAXtest | lost | /192. |

add Enter the serial n. search previous current No. 1 page / total 5 page next 1 Go

Fig 8.15




Fig 8.16




Fig 8.17




Fig 8.18

3> Data reading

A. Basic production reading, Energy today, total production, revenue today and accumulative revenue are showing on this page.




Fig 8.19

B. Plant data page can check device power, voltage curve by time, day, month or year.




Fig 8.20

4>Set up the equipment
The device management page selects MAX. The serial number of the device to be set can be found in the list.

Notice: The following operations are requested by professionals.




Fig 8.21




Fig 8.22

5>Check detailed data
Double-click the device serial number in the device list. The detailed data page is displayed. Data pages can be viewed by date or exported.





Fig 8.23

| History Data | | | | | | | |
|--------------|---------------|---------------------|-----------|---------------|---------------|---------|---------|
| | | start date | 2018-05-2 | end date | 2018-05-2 | search | export |
| No. | Serial number | Time | Status | EacToday(kWh) | EacTotal(kWh) | Vpv1(V) | Vpv2(V) |
| 1 | SASF803004 | 2018-05-28 17:22:30 | Normal | 235.6 | 1341.0 | 542.6 | 609.0 |
| 2 | SASF803004 | 2018-05-28 17:22:23 | Normal | 235.6 | 1341.0 | 543.4 | 611.9 |
| 3 | SASF803004 | 2018-05-28 17:22:16 | Normal | 235.6 | 1341.0 | 552.7 | 612.8 |
| 4 | SASF803004 | 2018-05-28 17:22:10 | Normal | 235.6 | 1341.0 | 549.4 | 617.2 |
| 5 | SASF803004 | 2018-05-28 17:22:05 | Normal | 235.6 | 1341.0 | 541.8 | 619.9 |
| 6 | SASF803004 | 2018-05-28 17:21:59 | Normal | 235.6 | 1341.0 | 543.6 | 619.2 |
| 7 | SASF803004 | 2018-05-28 17:21:53 | Normal | 235.6 | 1341.0 | 542.5 | 622.5 |
| 8 | SASF803004 | 2018-05-28 17:21:48 | Normal | 235.6 | 1341.0 | 537.0 | 615.8 |
| 9 | SASF803004 | 2018-05-28 17:21:40 | Normal | 235.6 | 1341.0 | 537.1 | 619.2 |
| 10 | SASF803004 | 2018-05-28 17:21:35 | Normal | 235.6 | 1341.0 | 540.3 | 624.9 |
| 11 | SASF803004 | 2018-05-28 17:21:29 | Normal | 235.5 | 1340.9 | 549.9 | 618.2 |
| 12 | SASF803004 | 2018-05-28 17:21:26 | Normal | 235.5 | 1340.9 | 544.2 | 608.8 |
| 13 | SASF803004 | 2018-05-28 17:21:17 | Normal | 235.5 | 1340.9 | 543.9 | 618.6 |
| 14 | SASF803004 | 2018-05-28 17:21:09 | Normal | 235.5 | 1340.9 | 543.3 | 614.4 |
| 15 | SASF803004 | 2018-05-28 17:21:05 | Normal | 235.5 | 1340.9 | 545.9 | 616.5 |
| 16 | SASF803004 | 2018-05-28 17:21:00 | Normal | 235.5 | 1340.9 | 544.9 | 617.6 |
| 17 | SASF803004 | 2018-05-28 17:20:55 | Normal | 235.5 | 1340.9 | 549.1 | 619.0 |

Fig 8.24

8.1.2.2 Shinemaster monitoring

This is a cost-effective and compact monitoring device that is specially designed for solar power plants, with a high-speed CPU and a stable Linux system that intelligently records the user's system characteristics.




RS485 twisted pair cable

Feature :

- 1> A versatile and high-performance communication data logger that notifies the user of system status at any time.
- 2> Flexible parameter setting, system information management, error prompting and recording, high-capacity storage.
- 3> Collect data and upload data to Growatt in real time over the network.

Note: The smart meter and environmental monitor must be Growatt's designated manufacturer, otherwise monitoring will not be possible. When RS485 of multiple machines is used in parallel, please connect the ground wire according to section 6.3.1.

The system framework of communication monitoring is shown in the figure below. Users can choose the most suitable monitoring method according to the actual situation.



1>ShineMaster IP Address query

A. The PC and shineMaster lan ports are connected to the router's port through the network cable, so that they are in the same local area network.

B. Go to the router's management page and check the "Internet host list" to query the IP address of the ShineMaster serial number as the name of the connected device. This IP is the IP address assigned by the router to the ShineMaster. If you do not know how to do this, contact your network administrator for operation.

Note: The router needs to enable automatic IP assignment, that is, open the DHCP function.

C. Enter the shineMaster IP address in the browser to enter the shineMaster built-in page.

2>ShineMaster Built-in page access

Before accessing, check whether the communication cable between the devices is securely connected. After the check is correct, you can enter the ShineMaster IP address in the IE browser to access the built-in page of the ShineMaster. As long as the ShineMaster is on the same network segment as the computer you are accessing, you can access the ShineMaster built-in server.

A. If the user successfully visits the shineMaster built-in page, they can go directly to the built-in page login interface, as shown in figure 8.25 below.




Fig 8.25

B. Enter user name and password, default login username: admin password: admin. click login after filling in, enter growatt shineMaster system page.

3>ShineMaster Data collector status view

Click on the status of the shineMaster data collector to view shineMaster "system state information", "serial number," server address, "number of connected devices," and so on.




Fig 8.26

4>ShineMaster Data collector add or delete device
ShineMaster Before monitoring photovoltaic devices, we need to enter the page of the built-in shinemaster data collector settings to add devices.

A. Add device

1. Select the monitoring mode for monitoring photovoltaic devices in the first drop-down list of add or remove devices.



Fig 8.27

2) Select the type of photovoltaic device monitored in the second drop-down list.




Fig 8.28

3) Fill in the third drop-down list with the photovoltaic device correspondence address.




Fig 8.29

4) Select "Add" and then click "Save".

5) Go to the device status page after saving success to confirm that the device was added successfully.



Fig 8.30

B. Delete device

- 1) Select the first drop-down list of "add or remove devices" to monitor the monitoring mode of photovoltaic devices.
- 2) Select the type of photovoltaic device monitored in the second drop-down list.
- 3) Fill in the third drop-down list with the photovoltaic device correspondence address.
- 4) Select the following "del" and click Save to complete the device addition.
- 5) Enter the device status page after successful save to confirm that the device was deleted successfully.

5> ShineMaster Data upload to ShineServer

A. Register, Login

- 1) Enter the server domain name in the computer browser to enter the shinesserver login page, if you are logged in for the first time, please register the user name. Enter the domain name access page, as shown in figure 8.32 below.
- Chinese user server domain name: <http://server-cn.growatt.com>.
 The domain name of the international user server is: <http://server.growatt.com>.

Fig 8.32

B. View monitoring data

- 1) After registration is complete, jump to the shinesserver main interface automatically. Click on "power station" and "work information" to display the information for the power station's total power flow chart on the same day. The drop-down list "Select collector" allows you to view the daily power flow chart of a single inverter for the power station.



Fig 8.33

Fig 8.31

- 2) Register user name, input user information according to prompt, after information is completed, click "register".
- Note: "collector serial number" and "collector check code" see shinemaster serialnumber box or guarantee box.

2) By clicking on "power station" and "equipment management" in turn, the real-time data of "data collector", "inverter", "environment monitor", "intelligent meter" and "confluence box" MAX "can be viewed.

8.2 Local Data Monitoring

MAX Inverter local data monitoring mode has a mobile phone app (phone) and PC direct connection, details are as follows.

8.2.1 Mobile phone app (Shinephone) Local Monitoring

8.2.1.1 Log on to app for local monitoring

Method 1

When you open the app login front page, click the top right corner toolbox icon. Pop up the toolbox, click the local debugging tool, and you can get the wifi name of the collector by scanning the QR code or barcode (The default password for WIFI is 12345678. If you have already connected, you can click "Skip" to connect directly to the WIFI.)




Fig 8.34

Method 2

Open app enter user name and password click login, enter me (personal center). Click the enter tool, find the local debugger to enter, and you can get the wifi name of the collector by scanning the QR code or barcode (The default password for WIFI is 12345678. If you have already connected, you can click "Skip" to connect directly to the WIFI.)




Fig 8.35

8.2.1.2 Use of local monitoring and debugging

When viewing local monitoring, you must keep the phone's wifi connected to the collector's wifi to view local monitoring (to enter the local monitoring page, first click auto refresh to get the latest data information).

Electricity generation: the option to view the latest generation, daily generation, monthly and annual generation of detailed information;

Power: you can see the current power and rated power value; failure: can read the equipment detailed fault information.

1>device control

Note: In addition to resetting the password to connect to the network, other WIFI modules that must connect to the collector can view information.

A.Reset password

Need network connection login oss account to set up or modify the local debug password.

B.Setting configuration

The configuration data of inverter, voltage, power and so on can be modified according to the usage (Fig 8.36).




Fig 8.36

C. Parameter configuration

The parameter data of the equipment can be modified according to the usage (Fig 8.37).

D. Intelligent detection

Detailed and accurate view of the device's detailed data and status (Fig 8.38).




Fig 8.37




Fig 8.38

E. Intelligent I-V curve scanning

Can remotely scan each mppt (Fig 8.39).




Fig 8.39

F. Fault recording detection

Remote, fast and accurate fault location (Fig 8.40).




Fig 8.40

G. Real-time recording detection

Inverter voltage and current quality can be observed in real time (Fig 8.41).




Fig 8.41

H. One click diagnosis

I-V curve diagnosis, grid waveform, THDV and cable impedance detection all at one click (Fig 8.42).

I. High level setting

According to the register address set parameters (professionals).

J. Device information

Check PV voltage/current, string voltage/current, AC voltage/current/power/frequency, PID voltage/current, internal parameters and device detail information and parameters (Fig 8.43).




Fig 8.42




Fig 8.43

8.2.2 U Disk Monitoring

Refer to 6.3.2 USB to WIFI/ U disk communicate connection, the local monitoring of U disk can realize the functions of software burning, fault recording, curve analysis and realtime recording. Details are as follows:

1>Firmware Programming

Create the bconfig.txt file under the root of the U disk, write to the following content, then insert the U disk to programming. Note the M3 program needs to be programming at last time.




Fig 8.44

2>Fault Recording

Create the bconfig.txt file under the root of the U disk, write the following content, then insert the U disk that can be read fault information, then generates a form under the files in the root directory, A total of 60 fault recording information is stored, the latest Numbers is 0.




Fig 8.45

3>Curve Analysis

Create the bconfig.txt file under the root of the U disk, write the following content, the insert U disk to record I-V curve, then generates a form under the files in the root directory.




Fig 8.46

4>Real Time Recording

Create the bconfig.txt file under the root of the U disk, write the following content, then insert U disk to read real time recording information, then generates a form under the files in the root directory, the form record's waveform is consistent with the ID of the command setting.




Fig 8.47

9.1 Routine Maintenance

9.1.1 Cleaning Inverter

| | |
|---|--|
|  DANGER | <ul style="list-style-type: none"> •Before any operation, please disconnect the DC switch and AC switch, and wait for at least 5 minutes until internal capacitance discharge completely. |
|---|--|

1>Check the ambient temperature and dust of the inverter, clean the inverter when necessary.

2>Observe whether the air outlets is normal, when necessary, clean the air outlets or clean the fan step by step, steps refer to 9.1.2.

9.1.2 Fan Maintenance

| | |
|--|---|
|  DANGER | <ul style="list-style-type: none"> •It must be carried out by qualified, trained personnel and comply with all prevailing local code and regulations. •Please disconnect the DC switch and AC switch before any operation, and wait for at least 5 minutes until the internal bus capacitance discharge completely. |
|  WARNING | <ul style="list-style-type: none"> •Do not use the air pump cleaning fan, which may cause fan damage. |

When the Growatt MAX series inverter work in high temperature environment, good ventilation and heat dissipation can effectively reduce the chance of load derating. Inverter equipped with internal cooling fans, when the internal temperature is too high, the fans work in to reduce the internal temperature. When the inverter is derating because of the internal temperature is too high, the following are the possible reasons or solutions.

- 1) Fan is blocked or the heat sink gathers too much dust, it needs to clean the fan, fan cover or heat sink.
- 2) Fan is damaged, it need to replace the fan.
- 3) Poor ventilation of the installation location, it needs to select the appropriate installation location according to the basic installation requirements.

Fan cleaning and replacement procedure;
 1>Please ensure that the DC side and AC side of the inverter have been disconnected before cleaning or replacement of the fan.

- 1) Turn off DC switch.
- 2) Disconnect DC terminals from inverter(Users need tools to disconnect the DC connection terminals).
- 3) Turn off AC switch.

2>Remove the screws on the fan guards with a cross screwdriver. it is shown as below.




Fig 9.1 External fan view




Fig 9.2 Internal fan view

3>Disconnect the wire connector of the fans with a flat head screw driver and remove the fans from the fan guards, it is shown as below.




Fig 9.3




Fig 9.4 External fan view




Fig 9.5 Internal fan view

Notice: MAX series inverter has four fans (internal fan*1Pcs, external fan*3Pcs).

4>Clean fan, fan guards and heat sink or replace fan.

- 1) Clean the fan and fan guards with air pump, brush or a damp cloth.
- 2) Remove each fan separately for cleaning if necessary.
- 3) Remove the fan that need to replace with a cross screwdriver, replace a new fan.
- 4) Tidy up the wire.

5>Install the fan, fan guard fixed and the inverter again.

9.2 Trouble Shooting



DANGER

- Work on the Growatt Max must be carried out by qualified personnel.
- Normally grounded conductors may be ungrounded and energized when a PV isolation low is indicated.
- Risk of electric shock.

9.2.1 Warning

Warnings identify the current status of the inverter(Max), warnings do not related to a fault and it does not affect the normal running of the inverter. When a warning with a number after it appears in the display, it indicates a warning code and is usually cleared through an orderly shutdown/re-set or a self-corrective action performed by the inverter.

| Warning | Description | Suggestion |
|-------------|--|--|
| Warning 100 | Fan abnormal | Contact Growatt |
| Warning 103 | NTC Broken | Contact Growatt |
| Warning 104 | DSP and COM firmware version unmatched | Contact Growatt |
| Warning 105 | Over Temperature | Contact Growatt |
| Warning 106 | SPD abnormal | Contact Growatt |
| Warning 107 | NE abnormal | Check if the neutral and ground cables are well connected and firm |
| Warning 108 | PV Circuit short | Contact Growatt |
| Warning 109 | PV boost driver broken | Contact Growatt |
| Warning 110 | String abnormal | Check if the polarity is reversed or short |
| Warning 111 | U disk overcurrent protection | Check if the USB port is connected to a short circuit |
| Warning 112 | Counter current prevention or Reactive power dispatching failure alarm | Contact Growatt |

Notice: MAX series inverter has three external fans and one Internal fan. If the suggestions do not work, please contact to Growatt.

9.2.2 Error

Errors codes identify a possible equipment failure, fault or incorrect inverter setting or configuration, any or all attempts to correct or clear a fault must be performed by qualified personnel.

Typically, the error code can be cleared once the cause or fault is removed.

Some of error code as table shows below, may indicate a fatal error and require you to contact the supplier or Growatt for help.

| Error Code | Description | Suggestion |
|------------|---|---|
| Error 101 | Communication error | Contact Growatt |
| Error 102 | Sample of main DSP and slave DSP are inconsistent | Contact Growatt |
| Error 106 | PV CurrSample Fault | Contact Growatt |
| Error 107 | AC CurrSample Fault | Contact Growatt |
| Error 108 | SPS Power Fault | Contact Growatt |
| Error 110 | Current over limit | Contact Growatt |
| Error 112 | AFCI Fault | Contact Growatt |
| Error 113 | IGBT drive fault | Contact Growatt |
| Error 114 | AFCI Module check fail | Contact Growatt |
| Error 117 | Relay fault | Contact Growatt |
| Error 120 | N - PE fault detection (PV - ground machine) | Contact Growatt |
| Error 121 | CPLD abnormal | Contact Growatt |
| Error 122 | Bus Fault | Contact Growatt |
| Error 124 | No AC connection | Check if the mains connection/mains voltage and frequency are correct |
| Error 125 | PV isolation low | Check panel and line insulation to ground is good |
| Error 126 | Leakage current too high | Contact Growatt |
| Error 127 | Output DC current too high | Contact Growatt |
| Error 128 | PV voltage high | Check PV actual voltage |
| Error 129 | Grid voltage fault | Check the actual voltage and wiring of the grid |
| Error 130 | Grid frequency fault | Check the actual frequency of the grid |

10 Specification

| Model Specifications | MAX 50KTL3 LV | MAX 60KTL3 LV | MAX 70KTL3 LV | MAX 80KTL3 LV |
|---|----------------------------|-------------------------|-------------------------|-------------------------|
| Input Data(DC) | | | | |
| Max. recommended PV power(for module STC) | 75000W | 90000W | 105000W | 120000W |
| Max. DC voltage | 1100V | | | |
| Start voltage | 250V | | | |
| Nominal voltage | 585V | 585V | 600V | 600V |
| MPP voltage range | 200V-1000V | | | |
| No. of MPP trackers | 6 | 6 | 7 | 7 |
| No. of PV strings per MPP trackers | 2 | | | |
| Max. input current per MPP trackers | 26A | | | |
| Max. short-circuit current per MPP trackers | 32A | | | |
| DC overvoltage category | Category II | | | |
| Output Data(AC) | | | | |
| AC nominal power | 50000W | 60000W | 70000W | 80000W |
| Max. AC apparent power | 55500VA | 66600VA | 77700VA | 88800VA |
| Nominal AC voltage/range | 230V/400V 340-440VAC | 230V/400V 340-440VAC | 230V/400V 340-440VAC | 230V/400V 340-440VAC |
| AC grid frequency/range | 50/60Hz 45-55Hz/55-65Hz | | | |
| Max. output current | 80.5A | 96.6A | 112.7A | 128.8A |
| Max. inrush current/duration | 20KA/tr:8us,tf:20us | | | |
| Max. output fault current/duration | 300A/30us | | | |
| Max. inverter backfeed current to PV array | 0A | | | |
| Power factor (@nominal power) | >0.99 | | | |
| Adjustable power factor | 0.8leading ...0.8lagging | | | |

| Model Specifications | MAX 50KTL3 LV | MAX 60KTL3 LV | MAX 70KTL3 LV | MAX 80KTL3 LV |
|----------------------------------|------------------|------------------|------------------|------------------|
| THDi | <3% | | | |
| AC grid connection type | 3W/N/PE | | | |
| AC overvoltage category | Category III | | | |
| Efficiency | | | | |
| Max. efficiency | 98.8% | 98.8% | 99.0% | 98.8% |
| Euro-eta | 98.4% | 98.4% | 98.5% | 98.5% |
| Protection devices | | | | |
| DC reverse-polarity protection | Yes | | | |
| DC switch | Yes | | | |
| DC Surge protection | Type II | | | |
| Insulation resistance monitoring | Yes | | | |
| AC surge protection | Type II | | | |
| AC short-circuit protection | Yes | | | |
| Grid monitoring | Yes | | | |
| Anti-islanding protection | Yes | | | |
| Residual-current monitoring unit | Yes | | | |
| String monitoring | Yes | | | |
| Anti-PID function | Optional | | | |
| AFCI protection | Optional | | | |
| Genertaal da | | | | |
| Dimensions (W / H / D) in mm | 860*600*300mm | | | |

| Model Specifications | MAX 50KTL3 LV | MAX 60KTL3 LV | MAX 70KTL3 LV | MAX 80KTL3 LV |
|--|---|------------------|------------------|------------------|
| Weight | 82kg | 82kg | 86kg | 86kg |
| Operating temperature range | -25°C - +60°C (derating over 45°C) | | | |
| Altitude | 4000m | | | |
| Internal consumption at | <1W(Note1) | | | |
| Topology | Transformerless | | | |
| Cooling | Fan cool | | | |
| Protection degree | IP65 | | | |
| Relative humidity | 0~100% | | | |
| DC connection | YF-H4 | | | |
| AC connection | Cable gland+OT terminal | | | |
| Interfaces | | | | |
| Display | LED/WIFI+APP | | | |
| RS485/USB | Yes | | | |
| PLC/GPRS/4G | Optional | | | |
| Warranty: 5 /10 years | Yes/Optional | | | |
| Certificates and approvals | | | | |
| Grid regulation | AS/NZS 4777.2,CEI 0-21,CEI 0-16,VDE-AR-N 4105, DIN V VDE V 0126-1-1,UTE C 15-712-1,EN 50438, IEC 60068,IEC 61683,IEC 62116,IEC 61727, MEA,PEA,DRRG/DEWA:2016,BDEW,G59/3 | | | |
| EMC | EN61000-6-2,EN61000-6-4 | | | |
| Safety | IEC/EN62109-1,IEC/EN62109-2 | | | |
| Note1. Self-consumption less than 25W when AC power supply at night. | | | | |

| Model Specifications | MAX 60KTL3 MV | MAX 70KTL3 MV | MAX 80KTL3 MV | MAX 90KTL3 MV | MAX 100KTL3 MV |
|---|----------------------------|-------------------|-------------------------|-------------------------|-------------------------|
| Input Data(DC) | | | | | |
| Max. recommended PV power(for module STC) | 90000W | 105000W | 120000W | 130000W | 130000W |
| Max. DC voltage | 1100V | | | | |
| Start voltage | 250V | | | | |
| Nominal voltage | 700V | 700V | 700V | 730V | 730V |
| MPP voltage range | 200V-1000V | | | | |
| No. of MPP trackers | 6 | 7 | 7 | 7 | 7 |
| No. of PV strings per MPP trackers | 2 | | | | |
| Max. input current per MPP trackers | 26A | | | | |
| Max. short-circuit current per MPP trackers | 32A | | | | |
| DC overvoltage category | Category II | | | | |
| Output Data(AC) | | | | | |
| AC nominal power | 60000W | 70000W | 80000W | 90000W | 100000W |
| Max. AC apparent power | 66600VA | 77700VA | 88800VA | 100000VA | 111000VA |
| Nominal AC voltage/range | 277V/480V 425- | 277V/480V 425- | 277V/480V 425-540VAC | 288V/500V 425-540VAC | 288V/500V 425-540VAC |
| AC grid frequency/range | 50/60Hz 45-55Hz/55-65Hz | | | | |
| Max. output current | 80.2A | 93.6A | 107.0A | 115.7A | 128.6A |
| Max. inrush current/duration | 20KA/tr:8us,tf:20us | | | | |
| Max. output fault current/duration | 300A/30us | | | | |
| Max. inverter backfeed current to PV array | 0A | | | | |
| Power factor(@nominal power) | >0.99 | | | | |
| Adjustable power factor | 0.8leading ...0.8lagging | | | | |
| THDi | <3% | | | | |

| Model | MAX 60KTL3 MV | MAX 70KTL3 MV | MAX 80KTL3 MV | MAX 90KTL3 MV | MAX 100KTL3 MV |
|----------------------------------|------------------|------------------|------------------|------------------|-------------------|
| Specifications | | | | | |
| AC grid connection type | 3W+PE | | | | |
| AC overvoltage category | Category III | | | | |
| Efficiency | | | | | |
| Max. efficiency | 99.0% | | | | |
| Euro-eta | 98.5% | 98.5% | 98.5% | 98.5% | 98.5% |
| Protection devices | | | | | |
| DC reverse-polarity protection | Yes | | | | |
| DC switch | Yes | | | | |
| DC Surge protection | Type II | | | | |
| Insulation resistance monitoring | Yes | | | | |
| AC surge protection | Type II | | | | |
| AC short-circuit protection | Yes | | | | |
| Grid monitoring | Yes | | | | |
| Anti-islanding protection | Yes | | | | |
| Residual-current monitoring unit | Yes | | | | |
| String monitoring | Yes | | | | |
| Anti-PID function | Optional | | | | |
| AFCL protection | Optional | | | | |
| General data | | | | | |
| Dimensions (W / H / D) in mm | 860*600*300mm | | | | |
| Weight | 82kg | 86kg | 86kg | 86kg | 86kg |

| Model | MAX 60KTL3 MV | MAX 70KTL3 MV | MAX 80KTL3 MV | MAX 90KTL3 MV | MAX 100KTL3 MV |
|--|---|------------------|------------------|------------------|-------------------|
| Specifications | | | | | |
| Operating temperature range | -25°C - +60°C (derating over 45°C) | | | | |
| Altitude | 4000m | | | | |
| Internal consumption at | <1W(Note1) | | | | |
| Topology | Transformerless | | | | |
| Cooling | Fan cool | | | | |
| Protection degree | IP65 | | | | |
| Relative humidity | 0~100% | | | | |
| DC connection | YF-H4 | | | | |
| AC connection | Cable gland+OT terminal | | | | |
| Interfaces | | | | | |
| Display | LED/WIFI+APP | | | | |
| RS485/USB | Yes | | | | |
| PLC/GPRS/4G | Optional | | | | |
| Warranty: 5 /10 years | Optional | | | | |
| Certificates and approvals | | | | | |
| Grid regulation | AS/NZS 4777.2,CEI 0-21,CEI 0-16,VDE-AR-N 4105, DIN V VDE V 0126-1-1,UTE C 15-712-1,EN 50438, IEC 60068,IEC 61683,IEC 62116,IEC 61727, MEA,PEA,DRRG/DEWA:2016,BDEW,G59/3 | | | | |
| EMC | EN61000-6-2,EN61000-6-4 | | | | |
| Safety | IEC/EN62109-1,IEC/EN62109-2 | | | | |
| Note1. Self-consumption less than 25W when AC power supply at night. | | | | | |

11 Decommissioning

If the inverter does not operate in the future, it needs to be properly disposed. The steps are as follows:

- 1>Disconnect the external AC short circuit and prevent reconnection due to misoperation.
- 2>Turn the DC switch to "OFF" position.
- 3>Wait at least 5 minutes until the internal capacitor discharge is completed.
- 4>Disconnect the AC connector.
- 5>Disconnect DC connector.
- 6>Remove the inverter from the wall.
- 7>Disposing of the inverter.

11.1 Disposing Of The MAX Series Inverter

| | |
|---|---|
|  | <p>Do not dispose of MAX series inverter together with household waste. Please accordance with the disposal regulations for electronic waste which apply at the installation site at that time. Ensure that the old unit and, where applicable, any accessories are disposed of in a proper manner.</p> |
|---|---|

12 Quality assurance

Please refer to related file.

Contact 13

If you have technical problems concerning our products, contact your installer or Growatt, please provide information below for better support.

- 1>Inverter type
- 2>Serial number of inverter
- 3>Error code of inverter
- 4>LED status of inverter
- 5>DC input voltage of inverter (Modules information)
- 6>Inverter communication method

Shenzhen Growatt New Energy Co., Ltd

4-13/F, Building A, Sino-German(Europe) Industrial Park,
Hangcheng Ave, Bao'an District, Shenzhen, China

T +86 0755 2747 1942

E service@ginverter.com

W www.ginverter.com