



Installation & Operation Manual



Download
Manual



🔍 Growatt New Energy

Shenzhen Growatt New Energy CO.,LTD
4-13/F,Building A,Sino-German(Europe) Industrial Park,
Hangcheng Ave, Bao'an District, Shenzhen, China

T +86 0755 2747 1942
E service@ginverter.com
W www.ginverter.com

GR-UM-261-A-00

Index

1 About the user manual

- 1.1 Manual description
- 1.2 Copyright statement
- 1.3 Applicable personnel
- 1.4 Manual usage

2 product introduction and installation

- 2.1 The product overview
- 2.2 Operating principle
- 2.3 Unpacking
- 2.4 Installation
- 2.5 Wiring instructions
- 2.6 Cable specification

3 operation and application

- 3.1 System block diagram
- 3.2 ShineMaster operation
- 3.3 Meter operation

4 Export limitation verification

- 4.1 Wiring verification
- 4.2 Export limitation verification

5 Remote monitoring (optional)

6 export limitation and self-consumption

7 common malfunctions

8 specification

9 contact us

1 About the user manual

1.1 Manual description

Dear user, thank you very much for using the Shine Master developed and produced by Shenzhen Growatt New Energy Co., Ltd.(Here in after referred to as Growatt).We sincerely hope that this product will meet your needs and expect you give more opinions on the performance and function of the product. The purpose of this manual is to provide users with detailed product information and instructions for installation, operation and maintenance.

1.2 Copyright statement

This user manual is copyrighted by Growatt. Any unit or individual may not excerpt or copy part or all of this user's manual without the written permission of the company. It may not be transmitted in any form, including materials and publications. Infringement must be investigated.

The version of this manual is V1.0.Growatt owns the final interpretation right of this user manual. If there is any change in product parameters, appearance, packing, etc. The latest information of the company shall prevail without notice.

1.3 Applicable personnel

This manual is intended for professional technicians who install, commission, and maintain Smart Energy Managers and those who perform daily operations. If necessary, refer to Growatt's corresponding user manual or instruction.

1.4 Manual usage

Please read this manual carefully before using Smart Energy Manager. At the same time, please keep this manual in a safe place so that operators and maintenance personnel can find out. The contents of the manual will be continuously updated and corrected. It is inevitable that there will be slight inaccuracies and errors in the actual contents. User should refer to the actual product purchased. The latest user manual can be downloaded from [can also be obtained through Growatt's sales or service channels.](#)

Installation 2

2.1 The product overview

2.1.1 Appearance




Figure 2-1 Appearance (Unit: mm)

Number	Description
A	Two antenna interface (optional)
B	RJ45 interface
C	Rs485 interface
D	CT Port
E	Voltage sampling interface
F	Ground terminal

2.1.2 Internal structure




Figure 2-2 Internal structure diagram


Number	Description
A	ShineMaster Status LED
B	Meter panel
C	Breaker
D	Terminal block

The Smart Energy Manager is mainly composed of ShineMaster, electricity meter, power supply, breaker and terminal block. The functions of each park are as follows:

- 1.ShineMaster:control core, data communication with inverter and electric meter, realize inverter power adjustment function and remote monitoring function.
- 2.Electricity meter: Real-time monitoring of voltage, current and function parameters.
- 3.Power supply: Power supply for ShineMaster.
- 4.Breaker: control the start and shutdown of the electricity meter and power supply.
- 5.Wiring terminal block: The place where the user wiring.

2.1.2.1 ShineMaster Status LED

There are 7 ShineMaster status LEDs,which can be used to display the running status of ShineMaster.



Number	Name	Description
A	Power LED	Power indicator light,constant on means power supply is normal.
B	Network LED	Network light: 1.off means fail to obtain IP address; 2.flashing means connecting to the server; 3.on means connection to the server successfully.
C	Device LED	The number of the LED continuously flashing means the device number connected to the ShineMaster.
D	Configuration LED	Flashing when configuration,if successful,the LED will be off(temporarily unavailable).
E	RF LED	RF signal indicator(temporarily unavailable).
F	4G LED	4G signal indicator(temporarily unavailable).
G	Status LED	LED flashes when ShineMaster is in a fault condition.

2.1.2.2 Meter panel



Figure 2-3 Meter panel

The panel of the meter can display various power parameters:voltage,current,active energy,active power,power factor,and so on.The display interface and setting parameters can be switched through the 4 buttons on the right side of the panel.For details,see section 3.3.

2.1.2.3 Breaker

When the switch is shipped from the factory, it is in the OFF state of the lower dial. After the customer connects all the wires of the Smart Energy Manager, turn the circuit breaker up, so that the circuit breaker is in the ON state, and the meter and ShineMaster will start normally.

2.1.2.4 Terminal block




Figure 2-4 Terminal block

The terminal block has a total of 13 wiring ports, from left to right: RS485 interface (485B, GND, 485A), current transformer interface (Ia1, Ia2, Ib1, Ib2, Ic1, Ic2), voltage sampling interface (L1, L2, L3, N).

2.1.2.5 Current transformer

Smart Energy Manager with different system capacity will deliver different type of split current transformers for detecting the current of the grid-connected access points in low voltage distribution system. The specifications are as follows:

System capacity	Current ratio	Precision degree	Through the number of turns	Outline size (mm) W*H*D	Through size (mm) a*e
50KW	100A/40mA	0.5	1	45*66.5*34.4	23.8*24.5
100KW	250A/40mA				

Note:

1. The total power of the inverter or the total power of the load in the whole system cannot exceed the system capacity corresponding to the Smart Energy Manager.
2. Under any conditions, the current flowing through the primary side of the current transformer (CT) must not exceed its maximum detection range.
3. The current transformer should not be operated in a high humidity environment.
4. The longest connection distance of the attached CT is 5M.

2.2 Operating principle

Note:

The Smart Energy Manager supports both Grid-tied inverter and Hybrid/AC Couple inverter, which are collectively referred to as inverter below.

The Smart Energy Manager works as follows:

1. The inverter converts the direct current generated by the sunlight to the photovoltaic string into alternating current.
2. The energy generated by the inverter can be used for user load, battery charging or output to the grid.
3. The Smart Energy Manager is located between the inverter, the user load and the grid, and detects the voltage and current of the grid connection point. According to the user's needs and settings, the inverter's output power is adjusted in real time to control the final output to the grid.

Photovoltaic grid-connected Export Limitation system block diagram:




Figure 2-5 Photovoltaic grid-connected Export Limitation system

Symbol	Description	Symbol	Description
A	Photovoltaic string	B	Grid-tied inverter or Hybrid/AC Coupled inverter with battery
C	Load	D	Smart Energy Manager
E	Grid		

2.3 Unpacking

Number	Description	Quantity
A	Smart Energy Manager	1
B	CT	3
C	Expansion pipe	2
D	Self-Tapping Screw	2
E	Key	1

2.4 Installation

Refer to the distance between the two wall-hanging holes in the figure below and make two holes in the wall. Insert the plastic expansion tube and lock the self-tapping screw on the plastic expansion tube. Fix the Smart Energy Manager on the wall and complete the installation.




Figure 2-6 Wall-mounting holes (unit: mm)

Note: This product provides a special key for locking the upper cover, and the customer can operate according to the actual situation.

2.5 Wiring instructions

Remove the screws of the front cover, and you can see mark of wiring labels on the bottom left. Do the wiring according to figure 2-7.




Figure 2-7 Wiring diagram of Export Limitation system

1. Overall wiring

As shown in the figure above, three current transformers and AC voltage sampling lines need to be placed between the load and the grid to detect the power of the grid access point in real time. The Smart Energy Manager is recommended to be installed near the power distribution cabinet and place the CT and AC voltage sampling lines in the power distribution cabinet.

2. RS485 interface

The RS485 interface of the Smart Energy Manager is used to connect the RS485 interface of the inverter. The wiring mode of multiple inverters can refer to the following figure. The notes are as follows:

(1) It is recommended to use shielded twisted pair cable for RS485 wire. The shielding layer is connected to the GND pin of RS485 interface of Smart Energy Manager and inverter.

(2) The inverter can only be connected to a maximum of 10 units, and the reference wiring diagram is wired in a daisy-chain topology. (Note: If the "Export Limitation" function is enabled, the inverter can only be connected to a maximum of 3 units.)




Figure 2-8 RS485 wiring diagram

3. Current transformer interface

There are P1 and P2 silk screens on both sides of the current transformer to distinguish the direction. Refer to Figure 2-7 for wiring. The P1 side is close to the grid and the P2 side is close to the inverter and load. The transformer connection is as follows:

- (1) White line of current transformer 1 (CT1) on inverter L1 is connected to Ia1, and black line is connected to Ia2,
- (2) White line of current transformer 2 (CT2) on inverter L2 is connected to Ib1, and black line is connected to Ib2,
- (3) White line of current transformer 3 (CT3) on inverter L3 is connected to Ic1, and black line is connected to Ic2,

Note:

- (1) Before the current transformer is installed, it must be connected to the smart energy manager twice to ensure that there is no open circuit on the secondary side of the transformer.
- (2) If the primary busbar on the site is a cable, it can be installed by the professional electricians. If the busbar is a copper busbar, the electrification operation requires a high degree of proficiency for the operator and requires installation protection measures.
- (3) When installing the current transformer, no foreign matter such as impurities or dust may fall into the cut surface of the core to avoid affecting the performance of the transformer.

Operation and application 3

4. Voltage sampling interface

Refer to Figure 2-7 to connect the voltage sampling line. According to the three-phase four-wires connection mode, L1/L2/L3/N must be connected, otherwise the Smart Energy Manager will not work properly.

5. RJ45 network cable interface

Pull a network cable from a router with a network and plug it directly into the RJ45 port of the Smart Energy Manager. This interface is used for remote monitoring. For details, see Chapter 5.

6. Ground terminal

In order to ensure the reliable operation and personal safety of the Smart Energy Manager, the grounding terminal on the outer casing must be reliably grounded. Note: The ground terminal should be waterproof.

2.6 Cable specification

Cable location	Cable cross-sectional area(mm ²)	
	Range	Recommended value
Rs485 wiring	1~2.5 (16~14AWG)	1 (16AWG)
Current transformer wiring	1~2.5 (16~14AWG)	2.5 (14AWG)
Voltage sampling wiring	1~2.5 (16~14AWG)	2.5 (14AWG)
Ground wire	2.5~4 (14~12AWG)	4 (12AWG)

3.1 System block diagram




Figure 3-1 Block diagram of the Export Limitation system

1. ShineMaster obtains meter data every 1s and performs Export Limitation regulation for the real-time power of the grid-connected access point.
2. In the Export Limitation system, turn on the Export Limitation function in the ShineMaster built-in interface.

1. ShineMaster obtains meter data every 1s and performs Export Limitation regulation for the real-time power of the grid-connected access point.
2. In the Export Limitation system, turn on the Export Limitation function in the ShineMaster built-in interface.

Export Limitation adjustment instructions:

- A: The inverter with the lowest rated power in the Export Limitation system,
- B: The inverter with the highest rated power in the Export Limitation system,
- P1: Control power (P1 = meter power + Export Limitation power, Export Limitation power can be positive or negative),
- P2: Idle power (P2 = inverter rate power - inverter actual output power P)

(1) When $-(A \text{ rate power} * 1\%) \leq P1 \leq (B \text{ rate power} * 1\%)$, Export Limitation regulation is not triggered.

(2) When the Export Limitation regulation is triggered and $P1 > (B \text{ rate power} * 1\%)$, the inverter is required to increase the power output. The system starts to adjust within 10s, and the inverters are sorted according to the idle power P2 from larger to smaller. If $P2 \geq P1$, then only the first inverter can be adjusted. If $P2 < P1$, the remaining required power (P1 - P2) is assigned to the next inverter, and so on.

For example, there are 20K, 60K inverters in the system, $60K * 1\% = 600W$, and $P1 > 600W$ for Export Limitation regulation.

(3) When the Export Limitation regulation is triggered and $-(A \text{ rate power} * 1\%) > P1$, the inverter is required to reduce the power output. The system starts to adjust within 10s, and the inverters are sorted according to the actual power P from large to small. If $P \geq |P1|$, then only the first inverter can be adjusted. If $P \geq |P1|$, the remaining power to be adjusted ($|P1| - P$) is assigned to the next inverter, and so on. For example, there are 20K, 60K inverters in the system, $20K * 1\% = 200W$, $P < -200W$ for Export Limitation regulation.

(4) If there are energy storage machines in the system, when the meter power is negative, the power flows to the grid. If the energy storage machines can be charged, the Export Limitation system adjusts energy storage machines for charging preferentially. If the power to the grid is larger than the charge power of the energy storage machines, the system will require inverter to reduce the power output.

Description of energy storage monitoring mode:
 The energy storage machine monitoring mode is a spontaneous self-use mode when the energy storage machine is operated in parallel with multiple machines, and the energy storage machines + inverter is working in parallel. The adjustment strategy is as follows:
 (1): The meter power is negative when the system power flows to the grid. If the energy storage machine can be charged at this time, the system adjusts the energy storage machine for charging.
 (2): The meter power is positive when the system power flows to the load. The system adjusts the energy storage machine for power output to the system, and reduces the power output from the grid.
 (3): The inverter is in a normal power generation state during the entire adjustment process, that is, the system does not adjust the output power of the inverter.

Note:
 (1): When triggering Export Limitation regulation and energy storage monitoring mode, the Smart Energy Manager intelligently distributes power according to the actual operating condition of the inverter. The actual adjustment process and the above instructions may vary slightly.
 (2): Selecting "NONE" is the normal monitoring mode. This mode only responds for obtaining and uploading all data in the system.

3.2 ShineMaster operation

3.2.1 Visit the ShineMaster built-in page

ShineMaster's built-in pages can be accessed through both static IP and dynamic IP access. And the parameters of ShineMaster can be set and modified.

3.2.1.1 Computer directly connected to ShineMaster's built-in page (static IP)

Connect the PC directly to the ShineMaster via the RJ45 cable. The computer IP is modified to 192.168.0.XXX (XXX is 2~253), and the default IP of ShineMaster is: 192.168.0.254. You can access the ShineMaster built-in page by entering 192.168.0.254 on your computer browser. Computer IP settings can refer to the following form:

ID address	192.168.0.5
Subnet mask	255.255.255.0
Default gateway	192.168.0.1

Note:
 Do not need to set the DNS server address. If the 4G communication function is enabled, you can only log in to the built-in page via dynamic IP.

3.2.1.2 Accessing the ShineMaster's built-in page through the router (Dynamic IP)

1. Connect the PC and ShineMaster to the same router so that they are on the same LAN.
 Note: The router must have DHCP enabled.
 2. Check the IP address of ShineMaster.
 Take the TP_LINK router as an example:
 Enter the management page of the router; click "DHCP Server-> Client List"; find the same client name as the serial number SN of the collector; this IP is the IP address assigned to the ShineMaster by the router. Ratio: ShineMaster serial number SN is: AEA3745001, the query result is as shown below:

ID	Client name	MAC address	IP address	Valid time
1	AEA3745001	00-47-8F-60-BF-34	192.168.100.101	01:30:32

Figure 3-2 Dynamic IP diagram by the router

3. Enter the ShineMaster IP address 192.168.100.101 into the ShineMaster built-in page in your browser.

3.2.2 Log in

1. After the user successfully accesses the ShineMaster built-in page, you need to log in to modify or set the parameters. As shown below:



2. Enter the user name and password, the default login user name: admin, password: admin, fill in and click on "login" to enter the ShineMaster system page.
 3. The system page mainly contains following 5 columns:
 A. Datalogger State, B. ExportLimit & Datalogger setting, C. Network Setting, D. System Management, E. Device State

3.2.3 ShineMaster Datalogger State

Click on the "datalogger state" section on the left side of the page to view information such as ShineMaster "System Status Information", "Serial Number", "Server Address", "Number of Connected Device".The operator can know the running information of ShineMaster from this column.

Datalogger information	
Connection status	Offline
SN	ZMD0933004
Server IP	server-cn.growatt.com
Server port	5279
Datalogger location IP	0.0.0.0
Time	5
Datalogger MAC	00:47:1F:B3:66:79
Hardware version	V1.0
Firmware version	1.0.5.9
Datalogger type	ShineMaster
Device number	0
Offline data number	3
Export limit enable	Enable
Export limit power (kW)	0
Baudrate	RS485_1: 9600;RS485_2: 9600

3.2.4 ShineMaster ExportLimit & Datalogger setting

Click the "ExportLimit & Datalogger setting" section on the left side of the page to perform Export Limitation function,add and delete device,and modify the baud rate.

3.2.4.1 Add device

1. Add one device at a time

Select the RS485 channel in the first drop-down list of "Add or Remove Device": "RS485_1"

(2)Select the type of PV device to be monitored in the second drop-down list: "INVERTER"

Device types parameter information:

- INVERTER: GROWATT Inverter;
- SDM120: EASTRON single phase meter;
- SDM630: EASTRON three phase four wire meter;
- CHNT_DDSU: ZT single phase meter;
- CHNT_DTSU: ZT three phase four wire meter;

(3)Fill in the communication address of the inverter in the third column.

(4)Select "Add" and click Save.

(5)After successfully saving,enter the "Device Status" page to confirm whether the device is added successfully.

Address	Device type	Device SN	Device state	Channel
001	INVERTER		Suspend	RS485_1
019	INVERTER	S123S456S7S6S7S8	Suspend	RS485_1
020	INVERTER		Suspend	RS485_1
004	CHNT_DDSU666		Suspend	RS485_2

The "Device State" in the above figure shows "normal", which means that the inverter or the meter is connected to the ShineMaster and is in normal communication.

2. Add multiple devices at once.

When there are multiple devices in a certain type and the addresses are consecutive, they can be added once on the system.

As shown below: Add 10 inverters with addresses 1~10 on RS485_1.

Export limit & Datalogger setting	
Meter channel	RS485_2 ▾
Meter address	2
Monitor mode	<input checked="" type="radio"/> NONE <input type="radio"/> Export limitation <input type="radio"/> Storage Parallel <input type="checkbox"/>
Reactive power regulation	<input type="radio"/> On <input checked="" type="radio"/> Off
Add or delete devices	RS485_1 ▾ INVERTER ▾ 1-10 <input checked="" type="radio"/> Add <input type="radio"/> Del
SCADA to Vietnam	<input type="radio"/> On <input checked="" type="radio"/> Off
Update firmware	<input type="radio"/> Yes <input checked="" type="radio"/> No
Reboot	<input type="radio"/> Yes <input checked="" type="radio"/> No
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	

3.2.4.2 Remove device

1. Delete one device at a time.

(1) Select the monitoring method for monitoring PV devices in the first drop-down list of "Add or Remove Devices".

(2) In the second drop-down list, select the type of PV plant being monitored.

(3) Fill in the PV device communication address in the third drop-down list.

(4) Select "Del" and click Save to finish removing of device.

(5) After successfully saving, enter the "Device State" page to confirm whether the device is successfully deleted.

Export limit & Datalogger setting	
Meter channel	RS485_2 ▾
Meter address	2
Monitor mode	<input checked="" type="radio"/> NONE <input type="radio"/> Export limitation <input type="radio"/> Storage Parallel <input type="checkbox"/>
Reactive power regulation	<input type="radio"/> On <input checked="" type="radio"/> Off
Add or delete devices	RS485_1 ▾ INVERTER ▾ 1 <input type="radio"/> Add <input checked="" type="radio"/> Del
SCADA to Vietnam	<input type="radio"/> On <input checked="" type="radio"/> Off
Update firmware	<input type="radio"/> Yes <input checked="" type="radio"/> No
Reboot	<input type="radio"/> Yes <input checked="" type="radio"/> No
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	

2. Delete multiple devices at once

You can delete certain types of devices in an address range continuously, but the types of devices must be the same.

As shown below: Delete the inverter with an address range of 1~10.

Export limit & Datalogger setting	
Meter channel	RS485_2 ▾
Meter address	2
Monitor mode	<input checked="" type="radio"/> NONE <input type="radio"/> Export limitation <input type="radio"/> Storage Parallel <input type="checkbox"/>
Reactive power regulation	<input type="radio"/> On <input checked="" type="radio"/> Off
Add or delete devices	RS485_1 ▾ INVERTER ▾ 1-10 <input type="radio"/> Add <input checked="" type="radio"/> Del
SCADA to Vietnam	<input type="radio"/> On <input checked="" type="radio"/> Off
Update firmware	<input type="radio"/> Yes <input checked="" type="radio"/> No
Reboot	<input type="radio"/> Yes <input checked="" type="radio"/> No
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	

Add and remove device notes:

(1) The second option: device type: All of Growatt's inverter products: PCS, HPS, MAX, MIN, MTL-P-US, SPC3000, SPC2000, SPH&SPA and other inverter models are selected as "INVERTER" in this item.

(2) When you need to delete a device, all the options should be the same with the moment you add this device like: 485 channel, device type, address, if you are not sure about this, you can check the device status first.

(3) When one address is occupied, you cannot just overwrite by adding the new device, you have to delete the old device and then use this address.

3.2.4.3 Export Limitation function setting

The Export Limitation function is not enabled by default at the factory. To use the Export Limitation feature, you can modify it through the configuration page.

1. Turn on Export Limitation function. The steps are as follows:

(1) Select "Export Limitation" in the "Monitoring mode" column;

(2) In the "MeterChannel" column, select the 485 channel "RS485_2" that connects the meter; (Default)

(3) Enter the 485 communication address of the meter in the "MeterAddress" column: 2; (Default)

(4) Enter the maximum power allowed to be delivered to the grid or allowed to be taken from the grid in the "Export Limitation Power(KW)" field. The default is 0;

Note: If you enter -100, the user is allowed to obtain a maximum of 100KW power from the grid. If the load exceeds 100KW, the inverter will rise output power. If enter 100, the system will allow to export 100KW to the grid. When the output of the grid exceeding 100KW, the system will limit the inverter power output.

(5) Select "ON" in the "Fallback activated" column to enable the Export Limitation failsafe function. When "OFF" is selected, "Active Power" and "Fallback activates after" will be invalid.

Note: If the "Fallback activated" column is "ON". When the communication between the inverter and the Smart Energy Manager fails, the inverter is not controlled by the Smart Energy Manager. When the communication failsafe time exceeds the "Fallback activates after" set value, the inverter will alarm and enter the Export Limitation failsafe state. The maximum output power of the inverter is limited to "Active Power" set value.

(6) In the "Active Power" column, you can enter 0~100, which means that when the Export Limitation function fails, all inverters participating in the Export Limitation adjustment limit the maximum output power by this percentage.

Note: One inverter is rated at 20KW and "10" is entered in this column. When the Export Limitation function fails, the maximum output power of the inverter is limited to $20KW * 10\% = 2KW$.

(7) Enter 10~5000s in the "Fallback activates after" field. When the inverter and Smart Energy Manager have a communication failure and exceed this set time, the inverters will alarm and enter the Export Limitation failsafe state.

The Export Limitation function is enabled in the above figure: Setting the meter which is 2 in the RS485_2 address as the Export Limitation meter, "Active Power" is set to 0 and this general recommended setting is 0. The inverter connected to the Smart Energy Manager's RS485 interface will actually be connected to the ShineMaster's RS485_1 channel and will participate in the Export Limitation regulation.

2. Turn off the Export Limitation function
The Export Limitation function is not enabled by default at the factory. If the Export Limitation function is enabled during installation and then you need to turn it off, simply select OFF in the "Export Limitation Function" field. Other options may be modified. Click "Save" to turn off the Export Limitation function of the entire system. As shown below:


Note:
Please select the "Energy Storage Monitoring" mode when the field application needs to enable the energy storage machine parallel or the spontaneous self-use function of energy storage machine + inverter.

3.2.4.4 Reactive power adjusting setting (This feature is temporarily unavailable)

The factory default is not to enable the reactive power adjustment function. If you want to use the reactive power adjustment function, you can modify it through the configuration page.


1. Turn on the reactive power adjustment function. The steps are as follows:
 - (1) Select "ON" in the "ReactivePower Adjustment Enable" column;
 - (2) In the "MeterChannel" column, select the 485 channel "RS485_2" that connects the meter; (Default)
 - (3) Enter the 485 communication address of the meter in the "MeterAddress" column: 2; (Default)
 - (4) Select the application scenario: NO_1, NO_2;
 - (5) Choose whether to enable reactive power priority. When reactive power priority is enabled, the rated reactive output power of the inverter increases. The specific increase depends on different inverters.
 - (6) Setting the system PF (Target PF value). (Can only be set in NO_2 scene)

Note:
(1): Application scenario NO_1, indicating the application is as follows:



The Smart Energy Manager is connected to the load. The meter shows the reactive power and PF of the load.

(2) :Application scenario NO_2,indicating the application is as follows:



The Smart Energy Manager is connected to the grid(Line voltage is less than 540V).The meter shows the reactive power and PF of the grid.

System reactive power compensation principle:The Smart Energy Manager obtains the reactive power of the meter and controls the inverter to output corresponding inductive and capacitive compensate for the reactive power consumed on the load side.

3.2.5 ShineMaster network settings

When you need to use the remote monitoring function of ShineMaster,you need to set up your network.Under normal circumstances,the network parameters have been set at the factory,and can be run according to the default configuration .


3.2.5.1 Collector network IP settings (default)

Click on the "Network Setting" section on the left side of the page to set up the network.
1.ShineMaster's Default setting of the DHCP function is "ON",it will automatically get IP address from router



2.If you need to set ShineMaster to a fixed IP,you need to set it as follows:


- (1)Select "OFF" in the "DHCP Enble" column to disable the DHCP function.
- (2)Set parameters such as IP,gateway,subnet mask,DNS,ect.,and then click "Save".As shown below:



3.2.5.2 Server address setting (default)

There are two ways to access the server: fill in the IP address and fill in the domain name address. You can only enable one of the two methods, please choose according to the actual use. The default setting at the factory is to connect to the server by domain name address.

1. Access the server by domain address
In the "ResolvDomain" column, select "ON", then the "Server IP" column will be grayed out. Set the domain name to : server-cn.growatt.com .As shown below:



2. Access the server by IP address

Select "OFF" in the "ResolvDomain" column, and the "Server Domain" column will be grayed out. Set the IP address to 120.77.127.135 .As shown below:

Network setting	
Network mode	LAN
DHCP	<input type="radio"/> On <input checked="" type="radio"/> Off
Local IP	192.168.100.102
Netgate	192.168.100.1
Netmask	255.255.255.0
DNS	192.168.100.1
Resolv domain	<input type="radio"/> On <input checked="" type="radio"/> Off
Server domain	server-cn.growatt.com Resolving
Server	120.77.127.135 NO CONN
Server port	5279
Data transfer interval	1 (Minutes)
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	

Note:

- (1):If the connection is a Growatt server, the columns "Server Port" and "Data Transfer Interval" are fixed and should not be modified by the user.
- (2):Non-special circumstances shall not use the fixed IP of the server to connect to the server. By default, the connection of the domain name is used.

3.2.6 Configuration page operation precautions

- 1.If you add a device, the interface will not be reflashed after clicking Save. Please restart the ShineMaster and click "Device State" to check whether the last operation was successful.
- 2.When configuring the parameters of the corresponding function, simply configure the parameters of the corresponding function as described above. Other parameters that are not related to the required configuration function should remain unchanged.

3.3 Meter operation

3.3.1 Displayed function

There are four buttons on the right of the monitor, they are "ESC (←) V/A", "↑ (Alt) MD/PH/HZ", "↓ (Shift) P" and "ENTER (→) E" from top to bottom. There are two ways to touch the button, long press(press more than two seconds) and short press(press for less than one second).

NO.	Button	Feature	Viewable content(Short press)
1		Short press: display voltage and current, ← Long press: ESC	Phase voltage, line voltage, phase current, neutral current, voltage harmonics, current harmonics
2		Short press: display power factor and frequency, ↑ Long press: Alt	Phase (total) frequency, total power factor, phase (total) maximum current demand
3		Short press: display power, ↓ Long press: Shift	Phase (total) active power, phase (total) reactive power, phase (total) apparent power
4		Short press: display energy, → Long press: Enter	Total active power, total reactive power, forward active power, reverse active power, forward reactive power, reverse reactive power

Figure 3-3 meter button and display feature

3.3.2 Programming operation

The default communication address of the meter is 02, the default baud rate is 9600 and the default current ratio is 100A/40mA for 50KW system, 250A/40mA for 100KW system. If the meter and the inverter cannot communicate normally, please confirm whether the communication address and baud rate are set correctly. Enter the setting menu (default password is 1000) for long pressing , and then short press and to find the option that needs setting.If the corresponding setting option is flashing, you can set by short pressing and . Otherwise, you need to short press first. When finished, long press to confirm, then short press several times to exit the setting menu.




Figure 3-4 Setting examples for current ratio

4 Wiring and Export Limitation verification

Before verifying, confirm that the inverter and the meter in the ShineMaster built-in page are connected, or log in the monitoring server to confirm that the inverter and the meter are online.

4.1 Wiring verification

Method 1: After completing the wiring, turn off all inverters, and all inverters output power is 0. At this time, if the load power is 20kW, the combined phase active power of the meter should be displayed as +20KW. This shows that the sampling point and CT wiring of the meter are correct.

Method 2: After the wiring is completed, the load is disconnected and the load power is 0. At this time, set "Export Power(KW)" to 10KW. If the inverter has enough illumination to output 10KW, the combined phase active power of the meter should be displayed as -10KW. This shows the sampling point and CT wiring of the meter are correct.

4.2 Export Limitation verification

After the wiring is completed, the Export Limitation function can be verified by observing the inverter power change.
Method: After setting "Export Power (KW)" to 0KW, disconnect the load. If the power of the inverter drop significantly to 0KW after 60s (the power displayed on the LCD screen or LED of the inverter becomes smaller), the Export Limitation function is normal.

Remote monitoring(optional) 5

The Smart Energy Manager can implement functions such as Export Limitation and Self-consumption locally. When ShineMaster is required to upload the monitored data to the Growatt server (ShineServer), ShineMaster needs to be added to the server. Access through domain names to view historical data, current data, data charts, historical data charts and so on.

1. Enter the server domain name on the computer browser and go to the ShineServer login page. If you are logging in for the first time, please register your username first. Enter the domain name access page as shown in Figure 5-1.

The server domain name of the Chinese user is: <http://server-cn.growatt.com>
The server domain name of the international user is: <http://server.growatt.com>




Figure 5-1 Shine Server login page

2. Register the user name, enter the user information according to the prompt, and fill in the information, click "Register".

The registration form includes the following fields and options:

- Country:** A dropdown menu.
- Username:** A text input field with a constraint: "No More Than 30 Characters".
- Password:** A text input field with a constraint: "Not Less Than 6 Digits".
- Password Confirm:** A text input field with a constraint: "Not Less Than 6 Digits".
- Language:** A dropdown menu currently set to "English".
- Phone Number:** A text input field.
- E-Mail:** A text input field.
- Installer Code:** A text input field.
- Agreement:** A radio button labeled "I have read and agree to the 《Privacy policy》".
- Next:** A blue button at the bottom of the form.

Figure 5-2 Shine Server register page

Note: "Collector SN" and "Collector CC" can be seen at the nameplate or accessory bag on the Smart Energy Manager, as well as the built-in page of ShineMaster. Refer to the figure below.



3. After the registration is completed, it will automatically jump to the main interface of Shine Server. Click "Sales Maintain" → "After-sales Inquiry" to view real-time data of "data Collector", "Inverter List" and "Smart Meter List".




Figure 5-3 Shine Server main interface


6 Export Limitation and Self consumption

In the "Dashboard" section of the monitoring(Shineserver and Shinephone) home page, when the Export Limitation function is turned on, it is displayed as an Export Limitation interface; when the Export Limitation function is turned off, it is display as a Self-consumption interface.

The monitoring page can display data such as power generation, power consumption, power supply back to the grid, and power consumption of the grid, and support remote monitoring and parameter setting.

1. Export Limitation page

When the Export Limitation function is turned on, the page will identify "Export Limitation is turned on" and display the power fed back to the grid and the power taken by the grid. The interfaces of Shineserver and Shinephone are as follows:



2. Self-consumption page

When the Export Limitation function is turned off, the page no longer identifies Export Limitation data and displays the system status of Self-consumption. The interfaces of Shineserver and Shinephone are as shown below:



Common malfunctions 7

Fault description	Fault performance	Troubleshooting method
After adding ShineMaster to the server, it has not been online for a long time.	ShineMaster's network LED is flashing for a long time.	<ol style="list-style-type: none"> 1.Ensure that the ShineMaster and the router network cable are connected properly. 2.The router needs to enable DHCP and the network is normal. 3.The router cannot block port 5279. 4.Refer to section 3.2.5.2.The international user website is server-cn.growatt.com
ShineMaster is online, the inverter is not online for a long time	ShineMaster's Device LED is off or the number of periodic flashes is not equal to the number of machines	<ol style="list-style-type: none"> 1.ShineMaster and inverter RS485 communication wiring is abnormal. 2.The device is not added to the ShineMaster built-in page. 3.The RS485 address of the added device is different from the actual RS485 address of the inverter. Adding the RS485 channel of the device is different from the actual RS485 channel of the inverter. Refer to section 3.2.4.2.
ShineMaster is online, smart meter is not online for a long time.	ShineMaster's Device LCD is off or the number of periodic flashes is not equal to the number of machines	<ol style="list-style-type: none"> 1.ShineMaster and inverter RS485 communication wiring is abnormal. 2.The device is not added to the ShineMaster built-in page. 3.The RS485 address of the added device is different from the actual RS485 address of the inverter. Adding the RS485 channel of the device is different from the actual RS485 channel of the inverter.
Export Limitation failure	The meter display data dose not match the Export Limitation effect	<ol style="list-style-type: none"> 1.The abnormality of the RS485 connection between ShineMaster and the inverter or meter. 2.The actual communication address of the inverter or meter is different from the added address. Current transformer wiring is misaligned or reversed.
The meter detection power value does not match the actual value	The power displayed by the meter is too much wrong with the actual value	<ol style="list-style-type: none"> 1.Current transformer wiring is misaligned or reversed. 2.Meter current ratio setting error.

8 Specification

Smart Energy Manager		
System capacity	50KW	100KW
Specification		
Input voltage data		
Normal input voltage/ range	230/400Vac 173~480Vac	
Normal input frequency/ range	50/60Hz 45-55Hz/55-65Hz	
AC grid connection type	3W/N/PE	
Input current and CT data		
Maximum detection current (CT primary current)	100A	250A
Maximum input current (CT secondary current)	40mA	
Current detection accuracy (CT)	0.5	
Interfaces		
RS485	Yes	
Ethernet	Yes	
Interver maximum connection number	10PCS	
Maximum communication distance	RS485 shielded twisted pair cable : 500m Ethernet cable : 100m	
General data		
Dimensions(W/H/D)	350*330*107mm	
Weight	6KG	
Operating temperature range	-25°C - +60°C	
Protection degree	IP65	
Relative humidity	0~100%	
Location	Indoor	
Altitude	2000m	
Terminal type	U shape terminal	
Certification		
Safety	CE	
Note: 1.The total power of the inverter or the total power of the load in the whole system cannot exceed the system capacity corresponding to the Smart Energy Manager.		

Specification 9

Growatt New Energy provides customers with a full range of technical support. Users can contact the nearest Growatt New Energy office or customer service point, or they can contact the company's customer service center directly.

Shenzhen Growatt New Energy CO.,LTD

4-13/F, Building A, Sino-German(Europe) Industrial Park,
Hangcheng Ave, Bao'an District, Shenzhen, China

T +86 0755 2747 1942

E service@ginverter.com

W www.ginverter.com